

WASHER FLUID RESERVOIR FOR 2022+ PETERBILT 579 & KENWORTH T680

Item Number: 26018

WASHER FLUID RESERVOIR INSTALLATION INSTRUCTIONS

- 1 Disconnect clamp from hose and drain washer fluid reservoir from the original tank.
- 2 Unplug/Disconnect plug from the original tank's washer fluid pump.
- 3 Unbolt and remove the reservoir.
- 4 Inspect the hose for any damage and replace if hose is worn.
- 5 Install and bolt down new washer fluid reservoir.
- 6 Reconnect and secure the hose to the pump with a hose clamp.
- 7 Open cap and fill the reservoir with washer fluid and check for leaks.
- 8 Operate windshield washer function on truck to ensure proper function of pump.

