



# UNITED PACIFIC INDUSTRIES

## 4" UNIVERSAL "PEEP" MIRROR WITH 12 VOLT LED TURN SIGNAL ARROW INSTALLATION INSTRUCTIONS

### ITEM # C5001-LED / C5001-CVXLED

1. Configure the mirror arm for the desired mounting position. The mirror head can be inserted on either side of the arm to change as needed lefthand to righthand. The base that clamps to the vehicle can be rotated as desired by loosening the single screw inside the base.
2. Before mounting to the vehicle, route the small wire in the groove on the mirror arm. Be sure to leave 1 inch of slack in the wire near the mirror head for mirror swivel adjustment. Once the wire is properly routed in the arm with slack near the mirror head, a couple small drops of "super glue" will help keep the wire secure in the groove.
3. Attach the mirror to the vehicle with the set screws.
4. Route the wire as desired to the interior of the vehicle, towards the turn signal switch wiring under the dash near the steering column. It may be necessary to run extra wire to reach the under dash area. The wire with the "white stripe" is 12v+ to the front LH or RH turn signal circuit. The other wire is grounded to the body.

