



United Pacific

HIGH POWER LED PROJECTOR HEADLIGHT

Item Numbers: 35839, 35840, 35865, 35866

Low Beam Adjuster (UP & DOWN):

Beam Down = (Clockwise: A+B Simultaneously)

Beam Up = (Counterclockwise :A+B Simultaneously)

Low Beam Adjuster (LEFT & RIGHT):

Beam Left = (Clockwise A+Counterclockwise B)

Beam Right = (Counterclockwise A+Clockwise B)



High Beam Adjuster (UP & DOWN):

Beam Up = (Clockwise: C+D Simultaneously)

Beam Down = (Counterclockwise: C+D Simultaneously)

High Beam Adjuster (LEFT & RIGHT):

Beam Left = (Clockwise C+Counterclockwise D)

Beam Right = (Counterclockwise C+Clockwise D)

Normal Fogging / Condensation


This bulletin provides information regarding headlights that may experience fogging or condensation inside of the headlamp assembly. A drop in air temperature may cause condensation to form on the inside of a cool headlamp lens. Generally, fogging is considered normal and can be eliminated by turning on the headlamp with the engine running for several minutes. In most cases, operating the vehicle in normal driving condition will clear the headlamp fogging. Headlamp assembly replacement **WILL NOT** be necessary in most cases.

Note

- If any of the following conditions occur, please consult with a professional mechanic to determine the water source:
 - If condensation/fogging fails to dissipate after operating the headlight with the engine running for 30 minutes
 - If water pooled inside the headlamp
- A high pressure washer may also cause water to be forced into the headlamp assembly.
- Adjust low and high beam aim before snapping front bezel in place.



United Pacific



No.	DESCRIPTION	QTY In Pkg
A	Screw-less Chrome Bezel	1
B	Stainless Mounting Screws	4
C	LED Module	1
D	United Pacific SS PB359 Style Housing	1
E	Wiring Harness (Not Shown)	1
F	SS Wire Loom (Not Shown)	1

Wiring Color Code

Black		Ground (-)
Green		Amber LED Turn Signal (+)
Yellow		White LED Position Light (+)
Red		Low Beam (+)
White		High Beam (+)


NOTE: High beam overrides low beam.
Both cannot be on at the same time.

Item No. 35839/35840/35865/35866
Product Name:
ULTRALIT PLUS - Full LED Projector
Headlight Assembly

Rev No. 03292022



United Pacific



REMOVAL INSTRUCTION:

1. insert trim removal tool, or other similar tool with a flat end into the notch opening on the bottom of the bezel. (careful not to scratch or damage the housing)
2. gently push the tool in and pry it forward.
3. the bezel should pop out from the bottom.
4. grab the bottom two corners of the bezel by hands.
5. gently lift up to remove the bezel from the light.

Item No. ULTRALIT PLUS & PLUS R
Front Bezel Removal Instruction

Rev No. 03292022